

# Kelly KHS series

High Voltage Opto-Isolated Sinusoidal BLDC Motor Controllers

## User Manual

### Devices Supported:

KHS32020I	KHS32030N	KHS32035N	KHS32040N
KHS36020I	KHS36025N	KHS36030N	KHS36035N
KHS32020IPS	KHS32030NPS	KHS32035NPS	KHS32040NPS
KHS36020IPS	KHS36025NPS	KHS36030NPS	KHS36035NPS
KHS32020IA	KHS32030NA	KHS32035NA	KHS32040NA
KHS36020IA	KHS36025NA	KHS36030NA	KHS36035NA

# Contents

<b>Chapter 1 Introduction</b> .....	2
1.1 Overview.....	2
<b>Chapter 2 Features and Specification</b> .....	3
2.1 General functions .....	3
2.2 Features .....	4
2.3 Specifications .....	5
2.4 Name Regulation.....	6
<b>Chapter 3 Wiring and Installation</b> .....	7
3.2 Connections.....	10
3.3 Installation Check List.....	16
<b>Chapter 4 Configuration Program</b> .....	17
4.1 Connecting to upper host. ....	18
4.2 How to use auto-Identification. ....	19
4.3 Program parameters and value .....	22
<b>Chapter 5 Maintenance</b> .....	30
<b>Contact Us:</b> .....	32

# Chapter 1 Introduction

## 1.1 Overview

**KHS is a sinusoidal motor controller specifically equipped with photo-electric isolation to meet high-voltage (Up to 360V) requirements.**

This manual introduces the features, installation, and maintenance of the Kelly sinusoidal brushless DC (BLDC) motor controller. Please read the manual carefully before using the controller. If you have any questions, contact the Kelly Controls support center.

**Kelly programmable motor controllers provide efficient, smooth, and quiet control for electric motorcycles, golf carts, go-karts, and industrial motor control.**

The primary design focus is to address noise issues in BLDC motor drive applications. The KHS motor controller must be used with Hall sensors and currently does not support sensor-less brushless motors.

Compared with the traditional trapezoidal control technology, this technology, based on sinusoidal drive technology, can reduce operating noise and switch loss by one-third, meeting the noise reduction and efficiency requirements of brushless DC motor applications. It uses high-power MOSFETs, SVPWM, and FOC, achieving up to 99% efficiency in most cases. A powerful microprocessor brings comprehensive and precise control to the controller. It also allows users to quickly and easily adjust parameters, conduct tests, and obtain diagnostic information. The KLS controller can be programmed on both PC software and Android App. The KHS features user-friendly I/O terminals, allowing customers to easily connect the battery and motor.

***Caution!***

**Before running the motor, please start the auto-identification operation first.**

**And do not attempt to connect the controller to the user program or change settings in the user program or Android App while the motor is still running.**

In other words, if you want to connect the controller to the user program or attempt to program, please stop the motor first. This is the first step you must take.

# Chapter 2 Features and Specification

## 2.1 General functions

1. Extended fault detection and protection. Customers can read the error message in PC software or Android APP also.
2. Monitoring battery voltage. The controller will stop driving if the battery voltage is too high. When the battery voltage is low, it will progressively cut back motor drive power as the battery voltage drops. It will also stop driving if the battery voltage reaches the preset "Low Battery Voltage" value.
3. Built-in current loop and over current protection.
4. Configurable motor temperature protection range.
5. Current cutback at low temperature and high temperature to protect battery and controller. The current begins to ramp down at 90°C case temperature, shutting down at 100°C.
6. The controller keeps monitoring battery recharging voltage during regen braking.
7. Maximum reverse speed and forward speed can be configured between 20% and 100% respectively and separately.
8. The controller can be programmed and configured using user program or an Android app. For the PC side, please connect the controller and PC using a Kelly USB cable or a USB-RS232 set to use the user program. For the Android side, please connect the controller to a Bluetooth adapter which purchased from out site to use the configuration app on Android devices.
9. Provision of a +5 volt and +12 volt output to supply various kinds of hall sensors and switches.
10. Multiple switches inputs. By default, the switch is effective when the voltage value is 12V.
11. 3 analog inputs (signal is 0-5V), the default are throttle analog input, brake analog input, and motor temperature input.
12. The controller will copy the pulse signal of A-phase Hall sensor for use in the pulse speedometer.
13. Configurable boost function. Enables the maximum motor output if the boost switch is turned on. Regardless of the throttle position, the effect will be the same as full throttle.
14. Configurable joystick throttle. A bi-symmetrical 0-5V signal for both forward and reversing.
15. Configurable motor over-temperature detection and protection with the recommended thermistor KTY84-130/150 or KTY83-122.
16. Only support three-phase hall position sensors. Open collector, pull up provided.
17. At Brake analog regen mode, controller needs another analog input as brake input.
18. Enhanced regen brake function. A novel ABS technique provides powerful and smooth regen. The regen can start at any speeds.
19. Cruise control. Only can be activated in forward direction.
20. Bluetooth supported. Required a Bluetooth adapter which needs to be purchased in addition from our website. This adapter is only useful for KLS controller.
21. User customization on the serial port communication is supported.

22. CAN Bus (Optional), broadcast type, with a customizable baud rate(default at 250Khz) . CAN bus is not included by default in KHS controllers.
23. Bidirectional anti-slip function (Optional), Prevent the stationary vehicle moving in the opposite direction. After the function enabled, when the controller detects that the motor turns from standstill to the opposite direction, it will drive the motor to provide some braking force, making the vehicle stops or slows down. The braking force can be set as required.
24. Electric-magnet brake (Optional).
25. Weak Magnetic Speed Boost Function (Optional).
26. Anti-theft function (Optional), an external alarm is required.
27. Other functions required by the user, require additional customization.

**Caution!**

**For safety reasons, regen must be used together with mechanical brakes.**

## 2.2 Features

1. Smart Control with Powerful Microprocessor.
2. Synchronous rectification, ultra-low voltage drop, fast SVPWM and FOC for very high efficiency.
3. Electronic commutation.
4. Monitoring of 3 motor phases, power bus, and power voltage.
5. Monitoring of 12V and 5V voltage sources.
6. Detection of current in all 3 motor phases.
7. Current control loop.
8. Hardware overcurrent protection.
9. Hardware overvoltage protection.
10. Configurable motor current and battery current limits.
11. Low EMC.
12. Battery protection: current reduction, warning, and shutdown at configured high and low voltage levels.
13. The PCB is mounted on an aluminum base plate with a heat sink on the bottom of the controller.
14. Various connector sets which supporting small signals, with waterproof connector set by default.
15. Thermal protection: current reduction, warning, and shutdown at high temperatures.
16. Automatic identification feature for Hall sensors mounted at any angle.
17. Configurable high pedal protection: if high throttle is detected at startup, the controller will not operate.
18. Current multiplication: drawing less current from the battery while outputting more current to the motor.
19. Easy installation: Operates with Just a 3-Wire Potentiometer.

20. Programming via standard PC/laptop, user program provided. Easy to use. No cost to customers.
21. Supports motors with any number of poles.
22. Standard electrical speed up to 70,000 eRPM (electrical speed = mechanical speed \* number of pole pairs; number of pole pairs = number of poles / 2).
23. Dust-proof and waterproof under sealed conditions, IP66.

## 2.3 Specifications

1. Frequency of Operation: 10KHz, 16KHz, 20KHz.
2. Standby Battery Current: < 0.5mA.
3. 5V or 12V Sensor Supply Current: 40mA.
4. Supply(PWR) Current: 30mA Typical.
5. Battery voltage(B+) range: Configurable.
6. Standard Throttle Input: 0-5V(3-wire resistive pot), 1-4V(hall active throttle).
7. Full Power Operating Temperature Range: 0°C to 70°C(MOSFET temperature).
8. Operating Temperature Range: -40°C to 100°C (MOSFET temperature).
9. Max Battery Current: Configurable.
10. Max Motor Current: Configurable.

## 2.4 Name Regulation

The name regulation of Kelly BLDC motor controllers:

For example: **KHS32020I/KHS32030NPS**

**KHS:** Kelly optical-isolated BLDC motor controller based on sinusoidal waveform which is suitable for operation under high voltage. KHS controllers can do regen brake function by default.

**320:** 320V battery pack.

**I:** Standard housing, smaller and lighter than N model, compatible with Hall sensors. Liquid cooled by default.

**N:** Sealed aluminum housing, Enhanced cooling performance, compatible with Hall sensors. Liquid cooled by default.

**IPS:** Standard housing, smaller and lighter than N model, compatible with Sin/Cosine sensors. Liquid cooled by default.

**NPS:** Sealed aluminum housing, Enhanced cooling performance, compatible with Sin/Cosine sensors. Liquid cooled by default.

**IA:** Standard housing, smaller and lighter than N model, compatible with ABZ Encoders. Liquid cooled by default.

**NA:** Sealed aluminum housing, Enhanced cooling performance, compatible with ABZ Encoders sensors. Liquid cooled by default.

<b>Kelly KHS High Voltage Sine Wave Brushless DC Motor Controller</b>			
Model	Nominal Voltage(Volt)	Peak Current 2 Minute (Amp)	Continuous Current(Amp)
KHS32020I/IPS/IA	18-380	200	80
KHS32030N/NPS/NA	18-380	300	150
KHS32035N/NPS/NA	18-380	350	175
KHS32040N/NPS/NA	18-380	400	200
KHS36020I/IPS/IA	18-450	200	80
KHS36025N/NPS/NA	18-450	250	125
KHS36030N/NPS/NA	18-450	300	150
KHS36035N/NPS/NA	18-450	350	170

Note: Continuous current was calculated based on controller with liquid cooling bottom plate.


# Chapter 3 Wiring and Installation

## 3.1 Mounting the Controller


The controller can be placed anywhere but should be kept as clean and dry as possible. If necessary, covering with a cover to prevent water and contaminants from entering.

To ensure full rated output power, the controller should be mounted on a clean, flat metal surface and secured with screws on all four mounting holes. Apply silicone grease or other thermally conductive material to the contact surfaces to enhance thermal performance.

Proper heat sinking and airflow are vital to achieve the full power capability of the controller. The case outline and mounting holes' dimensions are shown below.




**Figure 1: KHS-I series**  
 mounting holes' dimensions  
 (dimensions in millimeters) +/B+/B-/U/V/W:M8



**Figure 2: KHS-N series**  
 mounting holes' dimensions  
 (dimensions in millimeters) +/B+/B-/U/V/W:M8

## 3.2 Connections

### 3.2.1 Pin definition of KHS Controller



DJ7091Y-2.3-11  
See from output side

Orange REV-SW (14)	Black GND (6)	White FWD (12)
Red 12V (11)	Yellowish 12V Brake (25)	Blue ECO (22)
Greenish CAN_H (33)	Pink PWR (7)	Brownish CAN_L (34)



DJ7091Y-2.3-21  
See from output side

Gray Foot_SW (15)	Green Throttle (3)	
Black GND (20)	D-Gray Meter (8)	
Purple 5V (4)	Brown Brake_AN (2)	Red 12V (11)



DJ7061Y-2.3-21  
See from output side

Black GND (21)	Raddle Temp (1)	Purple 5V (5)
Yellow Hall A (18)	D-Green Hall B (17)	D-Blue Hall C (16)

Figure 10: waterproof connector

#### DJ7091Y-2.3-11 Pin Definition

1. REV\_SW(14): Reverse switch input. ※Orange
2. GND(6): Signal return or power supply return. ※Black
3. FWD(12): Forward switch or can be enabled as High speed switch function. ※White
4. 12V(11): 12V Supply. ※Red
5. 12V (25): brake switch. ※Yellowish
6. ECO(22): Low speed switch. ※Blue
7. CAN-H(33): (Optional function). ※Greenish
8. PWR(7): Controller power supply (input). ※Pink
9. CAN-L(34): (Optional function). ※Brownish

#### DJ7091Y-2.3-21 Pin Definition

1. Foot\_SW(15): Throttle switch input. ※Gray
2. Throttle(3): Throttle analog input, 0-5V. ※ Green

3. **GND(20): Signal return. ※Black**
4. **Meter(8): Copied signal of hall-A sensor. ※Dark Gray**
5. **5V(4): 5V Supply, <40mA. ※Purple**
6. **Brake\_AN(2): Brake variable regen or Boost function. ※Brown**
7. **12V(11): 12V Supply. ※Red**

#### **DJ7061Y-2.3-21 Pin Definition**

1. **GND(21): Signal return. ※Black**
2. **Temp(1): Motor temperature sensor input. ※Raddle.**
3. **5V(5): 5V Supply, <40mA. ※Purple**
4. **Hall A(18): Hall sensor signal of phase-A. ※Yellow**  
**(Also used as Sine signal input on KHS-NPS)**
5. **Hall B(17): Hall sensor signal of phase-B. ※Dark Green**  
**(Also used as Cosine signal input on KHS-NPS)**
6. **Hall C(16): Hall sensor signal of phase-C. ※Dark Blue**  
**(This port is reserved on KHS-NPS)**

### 3.2.2 35pin connector definition




Figure 11: 776164 35pin connector

#### 776164 Pin Definition

01	CTR_PWR(KEY)	02	COIL_RLY-	03	REV_SW	04	FWD_SW	05	12V_OUT
06	TPS2	07	GND	08	VS_5V	09	FOOT_SW	10	12V_OUT
11	CAN_H	12	12V_OUT	13	CTR_PWR(COIL_RLY+)	14	ECO	15	VS_5V
16	SC	17	SA	18	SB	19	ACC_SW	20	TPS
21	TX	22	RX	23	METER	24	ALARM	25	SD
26	BRK_AN/SW	27	GND	28	GND	29	GND	30	MOT_TEMP
31	GND	32	GND	33	GND	34	CAN_L	35	35 GND


- 01 PWR(7):** Controller power supply (input).
- 02** Reserved\*.
- 03 REV\_SW(14):** Reverse switch input
- 04 FWD(12):** Forward switch or can be enabled as High speed switch function.
- 05 12V(11):** 12V Supply.
- 06** Reserved\*.
- 07 GND(6):** Signal return or power supply return.
- 08 5V(5):** 5V Supply, <40mA.
- 09 12V (25):** brake switch.
- 10 12V(V+):**12V Supply for Communication Port.
- 11 CAN-L(34):** (Optional function).
- 12 12V(11):** 12V Supply.
- 13** Reserved\*.
- 14 ECO(22):** Low speed switch.
- 15 5V(4):** 5V Supply, <40mA.
- 16 Hall C(16):** Hall sensor signal of phase-C. (This port is reserved on KLS-8080NPS)
- 17 Hall A(18):** Hall sensor signal of phase-A. (Also used as Sine signal input on KLS-8080NPS)
- 18 Hall B(17):** Hall sensor signal of phase-B. (Also used as Cosine signal input on KLS-8080NPS)
- 19 Foot\_SW(15):** Throttle switch input.

- 20 Throttle(3): Throttle analog input, 0-5V.**
- 21 Tx of Communication Port.**
- 22 Rx of Communication Port.**
- 23 Meter(8): Copied signal of hall-A sensor.**
- 24 Reserved\*.**
- 25 Reserved\*.**
- 26 Brake\_AN(2): Brake variable regen or Boost function.**
- 27-28,31-32: Reserved GND.**
- 29 GND(20): Signal return.**
- 30 Temp(1): Motor temperature sensor input.**
- 33 GND(V-): GND for Communication Port.**
- 34 CAN-L(34): (Optional function).**
- 35 GND(21): Signal return.**


**Notes:**

1. PWR(7) should be connected to a 12V independent battery or a 12V DC-DC converter
2. All GND pins are internally connected.
3. Meter function is to output signal of hall-A sensor.
4. Three gears and three speeds function can't be used at the same time by default. Because FWD in three gears and High-speed in three speeds are using the same pin (FWD, Pin12).
5. The switch signal is valid at 12V.
6. 12V output (Pin11) can only be used for switch signals , with a total current not exceeding 40mA.
7. CAN bus is not included in KHS controller by default.
8. Boost and brake analog regen use the same port on Brake\_AN(Pin2). When boost is disabled in user program, Pin2 is used for brake analog regen . When boost is enabled, Pin2 is used for boost function. Due to port conflicts, these two functions can't operate simultaneously on the same port.
- 9. Reserved\*: Can be customized to implement other functions.**

### 3.2.3 KHS Controller Standard Wiring



**Figure 1: KHS-I/N controller standard wiring**  
(Battery is also used as controller's power supply)



**Figure 2: KHS-I/NPS controller standard wiring**  
(Battery is also used as controller's power supply)


**Caution!**

**Make sure the controller wiring is correct and has been double checked, especially the B+ and the B- of the controller before power on. Wiring faults will damage the controller. Ensure that the B- wiring is securely and properly connected before applying power. The preferred connection of the system contactor or circuit breaker is in series with the B+ line.**

**Contactors in the B+ line must have a diode across their coils. It was used as freewheel diode. Lacking of this diode may cause serious damage to the power module. Please install this diode as KHS controller standard wiring showing above.**

### 3.2.3 Communication Port

A 4pin connector is provided to communicate with host for calibration and configuration.



**Figure 12:** SM-4P connector

## 3.3 Installation Check List

1. Conduct a visual inspection to ensure that components such as mounting holes, wiring, and sealing rings are intact.
2. Check the connection between the battery B+ and NC. For controllers without a fuse, check the connection between the battery B+ and the controller B+ instead of NC.
3. Check the connection between the battery B- and the controller B-.
4. Verify the connections of all signal wires and ensure that their PWR and GND are properly isolated from each other.
5. Check the connection of the motor's Hall wires, the 5V and GND wires should correspond with the motor's interface.
6. Verify the connection of the throttle wires, the 5V and GND wires should correspond with the throttle's interface.
7. Check the connection of the gear wires. It is valid at 12V by default.

# Chapter 4 Configuration Program

KLS Configuration program allows users to adjust various parameters according to their needs, enabling the motor to achieve optimal performance. The default parameters may not be suitable for all situations. Please ensure that all parameters are adjusted to appropriate values before testing to avoid any potential dangers. Customers can program using either a PC program or an Android app.

Before operating the motor, an **automatic identification process must be performed**. During the process, the controller needs to be connected to the batteries, motor, and throttle. And the PWR(Pin7) needs to be connected with battery B+ to power the controller.

Please perform the automatic identification process according to the automatic identification guide showed in chapter 4.2.

### Notes.

1. **When configuring existing parameters in the user program or Android app, disconnect the controller from the motor or at least stop the motor.**




Figure 13 Warning window

2. **The controller may display fault codes when adjusting parameters, but it will not affect programming or configuration. However, it will affect the auto-identification operation, so please try to eliminate error codes before performing the auto-identification operation.**
3. **Use the RS232-USB cable and SM-4P adapter provided by Kelly to connect to a host computer. During the operation, the PWR of the controller needs to be provided with >+18V (for a 24V controller, provide >+8V). Connect the GND to battery B- .**
4. **To connect to Android devices, KLS controller requires a Bluetooth adapter.**

## 4.1 Connecting to upper host.

You have three ways to connect the controller to host computers or Android devices:

1. Using Kelly USB cable, connect SM-4P (Female) from controller to the USB port on computer. You may download Kelly USB Cable driver or at our website.

(<https://media.kellycontroller.com/new/CH341SER.zip>)



**Figure 14:** Kelly USB Cable

2. Using RS232-USB cable along with SM-4Pin adapter, connect SM-4Pin(Female) from controller to the USB port on computer. You may download USB-RS232 driver at our website. (<https://media.kellycontroller.com/new/USB-CONVERTER-RS232-Win10.zip>)



**Figure 15:** RS232-USB (left) and SM 4-Pin (right) adapter

3. Using Bluetooth adapter. Connect it to SM-4P (Female) then connect the controller to Android devices through Bluetooth. This Bluetooth adapter can be purchased from our website. (<https://kellycontroller.com/shop/usb-adapter>)




**Figure 16:** Bluetooth Adapter

## 4.2 How to use auto-Identification.

Here is a brief overview of the automatic identification process:

1. Connect the controller and the motor according to the **standard wiring diagram (Figure 11)**. Please make sure there is no load on the motor shaft before starting the programming.
2. Connect the controller to PC by using a Kelly USB cable or an USB to RS232 set. For Android devices, please use the Bluetooth adapter to connect the controller.
3. Download the corresponding USB drivers and the user program from our website, only one driver can be installed, two drivers installed at same time are incompatible. After the USB driver is successfully installed, please restart your PC.
4. Turn the key switch to supply power to the controller from B+/B- and PIN7, then open the user program on your device. Click the 'READ' button to open the initial interface as the figure below.



**Figure 17:** User program initial interface

Please check whether the value of Identification\_Angle is at 85. The 85 means this controller had finished the automatic identification operation with the motor in factory before. It is still needed to run automatic identification operation before running.

5. Fill 170 in the Identification\_Angle value. Then click the write button. The user program will give a pop-up window which shows the Write operation is succeeded. Then exit from the user program and turn off the power supply.

6. Turn on the power supply after the power supply is off for a few seconds. The motor shaft will try to run on random directions. This is a normal operating phenomenon.
7. Wait about 2-3 minutes.
8. The indicator will show error code 3-2, means automatic identification operation is finished normally. And you will see reset error message in the monitor screen of user program.
9. Turn off the power supply again, then wait about a few seconds to turn on the power supply again.
10. Connect the controller to user program. You will see 85 in the Identification\_Angle. Means, the controller auto-identification operation is succeeded. The motor is ready to run.
11. If Identification\_Angle value is 170, it means that auto-identification is still in progress.
12. If no error code is triggered, please do not manually write 85 to Identification\_Angle or restart the power supply.
13. If a constant error code lasts above 5 minutes and there are other error codes such as Identify error, hall error etc, please return to the initial interface of user program and write 85 to Identification\_Angle manually.
14. Before turn off the power supply ,make sure that Identification\_Angle is not at 170.Otherwise the controller will try to keep doing identification operation all the time after you turn on power supply again.When the error codes occur, please quit from user program and try step 6 again.
15. After successful identification, make sure that Identification\_Angle is not at 170.Then you may turn on the power supply.
16. If the direction of the motor is not what you expected, there is no need for you to operate again, just check the Change Direction option in the last part of initial interface then click Write button and reset, the motor will run on the opposite direction.
17. For NPS model (with sin/cosine sensors), please set Speed\_sensor to 4 first. And set Motor\_Poles to an appropriate value according to your motor . Then fill the Line\_Hall\_Zero , Line\_Hall\_Amplitude and Line\_Hall\_High,Line\_Hall\_Low with appropriate values.  

$$\text{Line\_Hall\_Zero} = [\text{HA\_AD}(\text{max}) + \text{HA\_AD}(\text{min})] * 2 \text{ or } [\text{HB\_AD}(\text{max}) + \text{HB\_AD}(\text{min})] * 2$$

$$= \text{Zero point voltage(V)} * 1024 / 5$$

$$\text{Line\_Hall\_Amplitude} = [\text{HA\_AD}(\text{max}) - \text{HA\_AD}(\text{min})] * 2 \text{ or } [\text{HB\_AD}(\text{max}) - \text{HB\_AD}(\text{min})] * 2$$

$$= \text{Signal amplitude(V)} * 1024 / 5$$

For high voltage controllers, additional steps are required during automatic angle identification, involving the pre-charge circuit board. The steps are as follows:



Figure 18: KHS-I terminals




Figure 19: KHS-N terminals

The controller includes a pre-charge circuit board between B+ and NC terminal.

First, connect a lower voltage (e.g. 24V-72V) to B+, the customer must set the pre-charge voltage to 0V in the user program before the controller can automatically identify.

When the identification angle operation is successfully completed, you need to set the pre-charge voltage and pre-charge time in the user program.

Then connect the positive pole of the high-voltage battery to NC to reach the pre-charge voltage set previously.

Pre-charge voltage range:

For 320V series, it should be 0-380V;

For 360V series, it should be 0-450V.

Pre-charge time: 0-200 (corresponding to the actual time 0-20S).

Customers can configure the target pre-charge voltage to be completed within the pre-charge time according to the battery characteristics.

## 4.3 Program parameters and value

On program's initial interface, these items are listed:

Number	Parameter	Possible Value	Default Value	Description	Source of Value*
1	Model Name			Controller Model.	Default
2	User Name			User code, to identify controller variants.	Default
3	Serial Number			Serial Number.	Default
4	Software Version			Software Version.	Default
5	Controller Volt	0-144		Controller Voltage(V).	Default
6	Low Volt	18-180		Minimum normal voltage(V), In order to protect the battery, if the battery voltage is lower than this value, the controller will not work.	User Configuration
7	Over Volt	18-180		Maximum normal voltage(V), In order to protect the battery, if the battery voltage is higher than this value, the controller will not work.	User Configuration
8	Hall	0-1000		Hall Galvanometer Rate(A).	Default
9	PhaseCurr Max	409-2048		The Max AD value of phase current.	Default

	AD				
10	Motor_Current	20-100%	100%	The ratio range of the motor phase current to the controller peak current.	User Configuration
11	Battery_Current	20-100%	50%	Maximum battery current. Used to set the upper limit of battery current to protect the battery. A lower value will limit the battery output current more and protect the battery more effectively. However, if this value is too low, it will affect acceleration.	User Configuration
12	Identify Angle	85 / 170	85	Status of identification: 85:normal operation. 170: A reboot is required to automatically identify the sensor angle. Once identification is complete, this value will be reset to 85.	Auto
13	TPS Low Err	0-20%	0%	Hall pedal parameter, only valid when TPS type is set to 2. When the actual value is lower than this value, the controller will report a TPS type error, 20%*5V=1V	User Configuration
14	TPS High Err	80-100%	95%	Hall pedal parameter, only valid when TPS type is set to 2. When the actual value is higher than this value, the controller will report a TPS type error, 80%*5V=4V	User Configuration
15	TPS Type	1 / 2	1	Throttle Type, 1: 0-5K,resistance pedal; 2: 0,5V,Hall active pedal;	User Configuration
16	TPS Dead Low	0-60%	20%	Throttle Dead Zone Lower Limit, 20%*5V=1V.	User Configuration
17	TPS Dead High	60-95%	80%	Throttle Dead Zone Higher Limit, 80%*5V=4V.	User Configuration
18	TPS Fwd MAP	0-100%	30%	When moving forward , the MAP value corresponding to throttle midpoint, to adjust throttle response amplitude.	User Configuration
19	TPS Rev MAP	0-100%	20%	When moving backward , the MAP value corresponding to throttle midpoint , to adjust throttle response amplitude.	User Configuration
20	Brake Type	0 / 1 / 2	0	Regen braking mode 0: Switch regen mode. 1:0-5K, resistance pedal regen. 2:0-5V, hall active pedal regen.	User Configuration
21	Brake Dead Low	5-40%	20%	Brake Dead Zone Lower Limit, 20%*5V=1V.	User Configuration
22	Brake Dead High	60-95%	80%	Brake Dead Zone Upper Limit,	User

				80%*5V=4V.	Configuration
23	Max Output Fre	50-1200	1000	Max output Frequency(Hz).	User Configuration
24	Max Speed	0-16000	4000	Motor max speed (RPM).	User Configuration
25	Max Fwd Speed	0-100%	100%	Maximum forward speed to the motor max speed .	User Configuration
26	Max Rev Speed	0-100%	100%	Maximum reverse speed to the motor max speed.	User Configuration
27	MidSpeed Forw Speed	0-100%	50%	Maximum forward speed in the middle speed gear .	User Configuration
28	MidSpeed Rev Speed	0-100%	30%	Maximum reverse speed in the middle speed gear .	User Configuration
29	LowSpeed Forw Speed	0-100%	50%	Maximum forward speed in the low speed gear .	User Configuration
30	LowSpeed Rev Speed%	0-100%	30%	Maximum reverse speed in the low speed gear .	User Configuration
31	Three Speed	0 / 1 / 2	0	Number of speed modes: 0: one speed mode: maximum speed mode. 1:two speed modes: middle speed mode and maximum speed mode . 2:three speed modes:low speed mode, middle speed mode and maximum speed mode.	User Configuration
32	PWM frequency	10 / 16 / 20	16	PWM modulation frequency (Khz)	User Configuration
33	IQ $K_p$	0-32767	500	$K_p$ of Q-ring, the proportional gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will accelerate the response speed but will increase startup jitter; decreasing this value will reduce startup jitter but will also decrease the response speed.	User Configuration
34	IQ $K_i$	0-32767	10	$K_i$ of Q-ring, the integral gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will improve current accuracy but will increase startup jitter and instability. Decreasing this value will enhance stability and reduce startup jitter but will also lower current accuracy.	User Configuration
35	ID $K_p$	0-32767	1500	$K_p$ of D-ring, the proportional gain in D-ring speed loop, is mainly effective at speeds below 400 RPM. Increasing this value will accelerate the response speed but will increase high-speed jitter; decreasing this value will reduce high-speed jitter but will also decrease the response speed.	User Configuration
36	ID $K_i$	0-32767	30	$K_i$ of D-ring, the integral gain in D-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will	User Configuration

				improve speed accuracy but will increase high-speed jitter and instability. Decreasing this value will enhance stability and reduce high-speed jitter but will also lower speed accuracy.	
37	HS_ACQR_Kp	0-32767	2000	Kp of Q-ring, the proportional gain in Q-ring current loop, is mainly effective at speeds above 400 RPM. Increasing this value will accelerate the response speed but will increase startup jitter; decreasing this value will reduce startup jitter but will also decrease the response speed.	User Configuration
38	HS_ACQR_Ki	0-32767	60	Ki of Q-ring, the integral gain in Q-ring current loop, is mainly effective at speeds above 400 RPM. Increasing this value will improve current accuracy but will increase startup jitter and instability. Decreasing this value will enhance stability and reduce startup jitter but will also lower current accuracy.	User Configuration
39	HS_ACDR_Kp	0-32767	5000	Kp of D-ring, the proportional gain in D-ring speed loop, is mainly effective at speeds above 400 RPM. Increasing this value will accelerate the response speed but will increase high-speed jitter; decreasing this value will reduce high-speed jitter but will also decrease the response speed.	User Configuration
40	HS_ACDR_Ki	0-32767	100	Ki of D-ring, the integral gain in D-ring current loop, is mainly effective at speeds above 400 RPM. Increasing this value will improve speed accuracy but will increase high-speed jitter and instability. Decreasing this value will enhance stability and reduce high-speed jitter but will also lower speed accuracy.	User Configuration
41	BRK_AD Brk	0-50%	0%	Brake pedal regen's regen strength, 0= no regen.	User Configuration
42	Anti-theft	0-30%	15%	When the anti-theft function is activated, the percentage of the motor's locking current to the maximum current.	User Configuration
43	Brk_Speed Limit	0-500	0	Minimum motor speed to activate regen brake (RPM), RPM below this value will exit regen.	User Configuration
44	RLS_TPS Brk	0-50%	0%	Pedal releasing regen 's regen strength, 0= no regen.	User Configuration
45	Ntl Brk	0-50%	0%	Neutral gear regen 's regen strength, 0= no regen.	User Configuration
46	Accel Time	1-250	5	Torque mode accelerate Time, the time of torque from 0 to max,(X0.1second)	User Configuration
47	Accel Rls Time	1-250	1	Torque mode accelerate release delay Time, the time of torque from max to 0,(X0.1second)	User Configuration
48	Brake Time	1-250	5	Torque mode Brake Time, the time of Brake Torque from 0 to max,(X0.1second)	User Configuration
49	Brake Rls Time	1-250	1	Torque mode Brake release Time, the time of Brake Torque from max to 0,(X0.1second)	User Configuration
50	BRK_SW Brk	0-50%	10%	Switch regen 's regen strength.	User

				0= no Switch regen.	Configuration
51	Change Dir Brk	0-50%	5%	Change direction regen's regen strength. 0= no Change direction regen.	User Configuration
52	Compensation	0-100%	20%	Compensation current of anti-slip function.	User Configuration
53	IVT BRK Max	0-10000	10000	Maximum motor speed for enable Change direction regen(RPM)	User Configuration
54	IVT BRK Min	0-5000	50	Minimum motor speed for enable Change direction regen (RPM)	User Configuration
55	Torque Speed $K_p$	0-10000	3000	<b><math>K_p</math> of Q-ring in torque mode</b> , the proportional gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will accelerate the response speed but will increase startup jitter; decreasing this value will reduce startup jitter but will also decrease the response speed.	User Configuration
56	Torque Speed $K_i$	0-500	80	<b><math>K_i</math> of Q-ring in torque mode</b> the integral gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will improve current accuracy but will increase startup jitter and instability. Decreasing this value will enhance stability and reduce startup jitter but will also lower current accuracy.	User Configuration
57	Speed Err Limit	50-4000	1000	Limit of $K_p$ and $K_i$ in torque mode, need to be adjusted at same time when adjusting $K_p$ and $K_i$ in torque mode.	User Configuration
58	Precharge_Vol	0-360	0	Target Voltage of Pre-charging ( V ).	User Configuration
59	Precharge Time	5-20	20	Time for pre-charging( S )	User Configuration
60	Motor Nominal	0-1000	80	Motor Current when identification(A)	User Configuration
61	Motor Poles	2-128	8	Number of motor poles, equal to 2* pole pairs. When used for hub motors, reducing this value by multiples, such as from 8 to 4, can improve the speed measurement accuracy.	User Configuration
62	Speed Sensor Type	2 /3/ 4	2	Sensor Type: 2. Hall sensor 3. Magnetic encoder. 4. Linear Hall sensor ( sine/cosine sensors ) 5.	User Configuration
63	Resolver Poles	2-32		Reserved.	User Configuration

64	Min Excitation	0-100	0	Minimum excitation coefficient (A) This value affects the current and maximum speed of the motor when the field weakening function is enabled. When this value = 0, the field weakening function has no actual effect	User Configuration
65	Motor Temp	0 / 1 / 2	0	Temperature sensor type, 0:none. 1: KTY84-130 and KTY84-150 2: KTY83-122	User Configuration
66	High Temp Cut °C	60-170	150	Temperature for triggering the motor's high temperature cut off.	User Configuration
67	Resume °C	60-170	110	When the temperature drops back to this value, high temperature resume will be triggered.	User Configuration
68	High Temp Str °C	0-170	100	starting temperature for high-temperature weakening. (°C)	User Configuration
69	High Temp weak	0-100%	50%	The strength of high-temperature weakening (%)	User Configuration
70	Line Hall Zero	1-1023		Zero point of sine/cosine sensor signal, this value / 1024 * 5 = actual voltage value (Volts). Available for sine/cosine sensor	User Configuration
71	Linear Hall Amplitude	1-1024		Signal amplitude of sine/cosine sensor signal. this value / 1024 * 5 = actual voltage value (Volts). When this value is below 153.6 or above 256,the signal voltage is error. Available for sine/cosine sensor	User Configuration
72	Line Hall High	1-1023		An error will be reported when the amplitude of the sine/cosine sensor signal exceeds this value. this value / 1024 * 5 = actual voltage value (Volts). Available for sine/cosine sensor	User Configuration
73	Line Hall Low	1-1023		An error will be reported when the amplitude of the sine/cosine sensor signal is below this value. this value / 1024 * 5 = actual voltage value (Volts). Available for sine/cosine sensor	User Configuration
74	Swap Motor Phase	0 / 1 / 255	0	Swap phase function status 0: disabled 1: enabled, 255: error. Available for sine/cosine sensor	Default
75	Synchro Initial Angle	0-65535	8192	Synchro Initial Angle , defines the reference point of the position when sensor type is set to 4. Available for sine/cosine sensor	Default

76	0° Hall value	0-7	2	Hall sensor sequence value at motor electrical angle 0°.	Auto
77	60° Hall value	0-7	6	Hall sensor sequence value at motor electrical angle 60°	Auto
78	120°Hall value	0-7	4	Hall sensor sequence value at motor electrical angle 120°	Auto
79	180°Hall value	0-7	5	Hall sensor sequence value at motor electrical angle 180°	Auto
80	240°Hall value	0-7	1	Hall sensor sequence value at motor electrical angle 240°	Auto
81	300°Hall value	0-7	3	Hall sensor sequence value at motor electrical angle 300°	Auto
82	Forward HA Rising edge	0-7	6	Forward Hall-A Rising edge sequence value	Auto
83	Forward HA Falling edge	0-7	1	Forward Hall-A Falling edge sequence value	Auto
84	Reverse HA Rising edge	0-7	5	Reverse Hall-A Rising edge sequence value	Auto
85	Reverse HA Falling edge	0-7	2	Reverse Hall-A Falling edge sequence value	Auto
86	Brake_SW_Level	0-255		Brake_SW_Level	Default
87	J CAN Address	0-255	5	CAN Address, when there are multiple CANs, different addresses need to be set	User Configuration
88	Startup H-Pedal	checked/ unchecked	checked	Startup High pedal function , Checked: From powerup, when the first time throttle being pressed, the controller will report a high pedal error to prevent accidental starting, need to step on the pedal again to start.	User Configuration
89	Brake H-Pedal	checked/ unchecked	unchecked	Brake High-pedal function Checked: When press the brake and throttle at the same time, he controller will report a high pedal error to stop running.	User Configuration
90	NTL H-Pedal	checked/ unchecked	unchecked	Neutral High-pedal function Checked: the first time throttle being pressed after switching gears, the controller will report a high pedal error to prevent accidental starting, need to step on the pedal again to start.	User Configuration
91	Joystick	checked/ unchecked	unchecked	Joystick throttle Checked: enable joystick throttle, Its range: 0-2.5V: forward 2.5V: neutral 2.5V-5V: backward. Has same range of dead zone as TPS dead zone.	User Configuration
92	Three Gears Switch	checked/ unchecked	unchecked	Three-gear function Check: Enable three operating gears: Forward, Neutral, Reverse. Uncheck: Forward only.	User Configuration
93	Boost	checked/ unchecked	unchecked	Boost function,	User

		unchecked		Checked: enable boost switch, Connect Brake_AN (PIN2) to 12V to start boost. Unchecked: Connect Brake_AN (PIN2) to 12V to start switch regen.	Configuration
94	Foot Switch	checked/ unchecked	unchecked	Throttle switch Checked: Connect Foot_SW to 12V to enable throttle, so motor can start.	User Configuration
95	SW Level	checked/ unchecked	checked	Defining which is the effective level of the switch. Checked: high level=enable. Unchecked: low level=enable.	Default
96	0,HIM;1,KIM	checked/ unchecked	checked	Controller type Checked: KIM. Unchecked: HIM.	Default
97	Cruise	checked/ unchecked	unchecked	Cruise function Check: Enable the cruise function. Press and hold the accelerator for more than 3 seconds to enter the cruise mode. If the eRPM is lower than 4000, the controller will automatically exit the cruise mode.	User Configuration
98	Anti-theft	checked/ unchecked	unchecked	Anti-theft function Checked: enable anti-theft function, Need to connect to external anti-theft device. When the alarm is triggered, the motor will resist being turned.	User Configuration
99	Anti-Slip	checked/ unchecked	unchecked	Anti-Slip function Checked: enable anti-slip function, The motor will resist rotation to prevent the vehicle from moving due to external forces.	User Configuration
100	Change Direction	checked/ unchecked	unchecked	Change Direction function Checked: Swap the forward and backward directions. Unchecked: no swap. Used to correct the motor from moving opposite direction after identification	User Configuration

**Source of Value \*:**

1. User : Users should modify these values to adjust the controller.
2. Auto: These values are generated by the sensor or the controller's program, and users can affect the operation of the controller by modifying these values.
3. Default: These values are factory presets or sensor readings , cannot be modified by the user program.

# Chapter 5 Maintenance

***Caution!***

**There are no user-serviceable parts inside the controller. Do not attempt to open the controller on your own, as this will void your warranty.**

**The exterior of the controller should be cleaned periodically.**

**The controller is a high powered device. When working with any battery powered vehicle, proper safety precautions should be taken that include, but are not limited to proper training, wearing eye protection, avoidance of loose clothing, hair and jewelry, using insulated tools.**

Although the controller virtually requires no maintenance after proper installation, it is recommended to follow these steps during use:

1. Disconnect the battery, starting with the positive terminal, to cut off the power.
2. Discharge the capacitors in the controller by connecting a load (such as a contactor coil, resistor, or horn) across the controller's B+ and B- terminals.
3. Regularly remove any dirt or corrosion from the bus bar area. Wipe the controller with a moist rag and ensure it is completely dry before reconnecting the battery.
4. Make sure the connections to the bus bars are tight. To avoid physically stressing the bus bars, use two well-insulated wrenches for the operation.
5. Fanned model require routine fan maintenance, including ensuring the fan rotate normally and cleaning the dust on the fan.

# Table 1: Error Codes

## External LED Error Codes

To display the error code, please install an external LED indicator first.

Error code		Explanation	Solution
1, 1	□ □	Auto-Identification failed	<ol style="list-style-type: none"> <li>1. Check Phase line or Hall line.</li> <li>2. Check Hall power line(+5V and GND).</li> <li>3. The motor load maybe too high. Please unload the motor before proceeding with identification.</li> </ol>
1, 2	□ □□	Over voltage error	<ol style="list-style-type: none"> <li>1. Battery voltage is too high for the controller. Check battery volts and controller configuration.</li> <li>2. Regeneration over-voltage. Controller will limit regen or stop regen. please reduce the regen ratio in configuration.</li> </ol>
1, 3	□ □□□	Low voltage error	<p>Battery voltage is too low, please check the battery and recharge.</p> <p>When the battery voltage continuously exceeds the low voltage cut-off value for 5 seconds, the controller will resume normal operation.</p>
1, 4	□ □□□□	The controller did not receive CAN commands	Resend CAN commands from VCU.
2, 1	□□ □	Motor stall	The motor did not reach 25eRPM within 2 seconds of starting. Please check the Hall signal lines and the phase line connections.
2, 2	□□ □□	Internal voltage error	<ol style="list-style-type: none"> <li>1. Check the connection between PWR and B+(For 8080N series, check connection between PWR and +12V; GND and -12V).</li> <li>2. The load on the 5V or 12V power supply could be too heavy, ensure that the measured voltage of the 5V power supply is not less than 4V and the voltage of the 12V power supply is not less than 8V. The lower these values are, the heavier the load on the power supply.</li> <li>3. If none of the above issues are present, the internal power module of the controller may be damaged. The controller needs to be sent back to the factory.</li> </ol>
2, 3	□□ □□□	Over temperature	The controller temperature is too high, about to stop. Please wait until it restore to 80℃.
2, 4	□□ □□□□	Throttle error at power on	Throttle signal is higher than the value of "TPS_dead_low" at power-on. Release the throttle and

			press again or adjust the TPS_dead_low value. If still can't fix the issue, check if the throttle is functioning properly.
3, 1	0000 00	Reserved	
3, 2	0000 00	Internal reset error	Current is too high or current fluctuations are too large. Reduce the phase current and check if the 5V and 12V power supplies are normal.
3, 3	0000 0000	Hall throttle is open or short-circuit	May occur after TPS_Type being set to 2. 1. The throttle might have an internal short circuit or the ground wire might be disconnected. 2. Set TPS_High_Err to 95 , check the throttle and its wiring, then restart to fix the issue.
3, 4	0000 0000	Angle sensor error	1. Speed sensor type error,customers may set the correct sensor type through user program or App. 2. Incorrect wiring. 3. Speed sensor is damaged or defective. Or feedback signal is erratic.
4, 1	00000 00	Switch-direction error	1. Throttle is not at 0 when switching motor direction. 2. Motor rotation speed is above 50RPM.
4, 2	00000 00	Reserved	
4, 3	00000 0000	Motor over-temperature	May occur after motor temp being set to 1 or 2. The Motor temperature has exceeded the configured maximum value. The controller will shut down until the motor temperature cools down.
4, 4	00000 0000	Hall Galvanometer sensor error	Hall galvanometer inside the controller is damaged.
Error codes can be read through PC software or Android app.			

## Contact Us:

**Kelly Controls**

**Home Page:**

<http://www.KellyController.com>

**Download user manual, instructions and user program:**

<https://kellycontroller.com/support/>

**E-mail:**

[Sales@Kelly-Controls.com](mailto:Sales@Kelly-Controls.com)

**Phone:** (01) 224 637 5092